

FIG. 1




FIG. 2




FIG. 3




FIG. 4





FIG. 5

501 Number	502 File name	503 Selected flag	504 Related information including the date and time of photography and GPS information					505 Pointer to thumbnail image data	506 Pointer to main image data
1	000	0						SP_1	MP_1
2	xxx	1						SP_2	MP_2
⋮	⋮	⋮						⋮	⋮
N	ΔΔΔ	0						SP_N	MP_N

500

5/15

FIG. 6



6/15

FIG. 7




FIG. 8





FIG. 9



9/15

FIG. 10




FIG. 11




FIG. 12

1201	1202	1203	1204	1205	1206	1207	1208	1209	1210	1211
Prefecture	Municipal	Area		Upper Left Latitude		Upper Left Longitude		Lower Left Latitude		Lower Left Longitude
Prefecture A	Town X	a	N	46 00 08	E	147 59 44	N	45 20 45	E	147 59 44
Prefecture B	Town Y	b	N	47 00 08	E	148 59 44	N	46 20 45	E	148 59 44
⋮	⋮	⋮		⋮		⋮		⋮		⋮
Prefecture C	Town Z	c	N	48 00 08	E	149 59 44	N	47 20 45	E	149 59 44

1201	1202	1203	1212	1213	1214	1215	1216	1217	1218	1219
Prefecture	Municipal	Area		Upper Right Latitude		Upper Right Longitude		Lower Right Latitude		Lower Right Longitude
Prefecture A	Town X	a	N	46 00 08	E	148 59 44	N	46 20 45	E	148 59 44
Prefecture B	Town Y	b	N	47 00 08	E	149 59 44	N	47 20 45	E	149 59 44
⋮	⋮	⋮		⋮		⋮		⋮		⋮
Prefecture C	Town Z	c	N	48 00 08	E	150 59 44	N	48 20 45	E	150 59 44

12/15

FIG. 13





FIG. 14



Reference numerals in the drawings

100	TV receiver
101	Tuner
102	Separator
103, 202	Controller
104, 203	Decoder
105	Video processor
204	Display controller
106, 205	OSD controller
107, 206	Synthesizer
108, 207, 1001	Display part
109, 201	Remote control signal transmitter-receiver
110	Media insertion unit
111	Media controller
112, 209	Display-image-list storage part
113, 210	Radio controller
1101	Map information storage part
200, 1000	Remote controller
207	Input unit
300	Image data
301	Header information
302	Main image related information
303	Thumbnail related information
304	Thumbnail image data
305	Main image data
401	Full screen mode
402	Slide show mode
403	Thumbnail mode
404	Related information mode
500	Display image list
501	Number
502	File name
503	Selected flag
504	Related information
505	Pointer to thumbnail image data

- 506 Pointer to main image data
- 1002 Thumbnail frame
- 1003 TV image display key
- 1004 Remote controller image display key
- 1005 Arrow key
- 1006 Enter key
- 1200 Map information
- 1301 Display area
- 1302 Photography-location-row display area
- 1303 Time-period-column display area
- 1304 Date display
- 1305 Previous-photography-date selection icon
- 1306 Next-photography-date selection icon